

# DC Leakage Current Sensor CYCT04-xnS20

This current sensor is based on magnetic modulation and compensation principle, and can be used for measurement of small DC current and leakage current, current difference between two or more conductors.

### **Product Characteristics:**

- Application of Computer Aided Ageing Technology
- 100% Ageing Processing and Thermal Drift Test under high operating temperature in order to guarantee the long term stability of the sensors
- Custom makeable according to individual requirements
- Various current and voltage outputs are selectable
- Power supply options: ±12VDC and ±15VDC, single power supply is possible.
- Sensors with window for contactless measurements

#### **Applications:**

- Isolation Monitoring of DC power systems and cable selection systems,
- Measurements of small DC currents and leakage currents etc.

### **Electrical Data**

Measuring range M	10mA ~ 2A DC
Linearity range	1.2 x M (measuring range)
Nominal output signals	0-5V, ±5V, 4-20mA, 0-20mA, ±20mA
Supply voltage	±12VDC, ±15VDC (±5%)
Current consumption	20mA + output current
Galvanic isolation	2.5KV RMS/50Hz/min
Measuring resistance for current output	≤250Ω
Load resistance for voltage output	≥10kΩ

### **Accuracy and Dynamic Performances**

Thermal drift of offset current	(Ta=-10°C~60°C) ≤400	ppm/°C
Response time	≤120	ms
Accuracy	±1.0	%FS
Linearity	≤1.0	%FS


## **General Data**

Operating temperature	-25 ~ +70	°C
Storage temperature	-40 ~ +85	°C
Window size	Ø20	mm
Case dimensions H x L x W	69 x 52.9 x16	mm

Tel.: +49 (0)8121 – 2574100 Fax: +49 (0)8121 – 2574101 Email: info@cy-sensors.com http://www.cy-sensors.com



### **Definition of Part number:**




(1)	(2)	(3)	(4)	(5)	(6)
Series name	Output signal	Power supply	Case style	Accuracy	Rated Input current (M=U/B + m)
CYCT04	x=1: ±5VDC x=2: ±20mADC x=3: 0-5V DC x=4: 0-20mA DC x=5: 4-20mA DC	n <b>=5:</b> ±12V DC n <b>=6:</b> ±15V DC	S20 With aperture Ø20mm	1.0%	m = 10mA, 20mA, 50mA,100mA,200mA, 500mA, 1A, 2A


U: unidirectional input current; B: bidirectional input current

Example 1:	CYCT04-56S20-1.0-U10mA, DC Current sensor with Output signal: 4-20mA DC Power supply: ±15V DC Rated input current: 0-10mA DC (unidirectional)
Example 2:	CYCT04-15S20-1.0-B10mA, DC Current sensor with Output signal: ±5V DC Power supply: ±12V DC Rated input current: -10mA ~ +10mADC (bidirectional)

## **DIMENSIONS (mm)**



Pin Arrangement					
Pin	1	2	3	4	
Function	+Vcc	-Vcc	OUT	GND	





Markt Schwabener Str. 8 D-85464 Finsing Germany

Tel.: +49 (0)8121 – 2574100 Fax: +49 (0)8121 – 2574101 Email: info@cy-sensors.com http://www.cy-sensors.com



## CONNECTION

The current carrying cable must pass through the window. The phase of output is the same as that of the current passing the window in the direction of the arrow indicated on the case.

### a) Voltage Output

- 1: +Vcc Power Supply
- 2: -Vcc Power Supply
- 3: Output
- 4: Ground


	1: +Vcc	
	2: -Vcc	Vo
CYCT04-S20	3: OUT	
	4: GND	$\heartsuit$
		•

#### Relation between Input and Output:

Sensor CYCT04-35	5S20-1.0-U10mA	Sensor CYCT04-15S20-1.0-B10mA		
Input current (mA) Output voltage (V)		Input current (mA)	Output voltage (V)	
0	0	-10	-5	
2.5	1.25	-5	-2.5	
5	2.5	0	0	
7.5	3.75	5	2.5	
10	5	10	5	

### b) Current Output

- 1: +Vcc Power Supply
- 2: -Vcc Power Supply
- 3: Output
- 4: Ground



#### Relation between Input and Output (for $R_m=250 \Omega$ ):

Sensor CYCT04-56S20-1.0-U10mA			Sensor CYCT04-45S20-1.0-B10mA		
Input current Output current		Output voltage	Input current	Output current	Output voltage
(mA)	lo(mA)	Vo (V)	(mA)	lo(mA)	Vo (V)
0	4	1	-10	0	0
2.5	8	2	-5	5	1.25
5	12	3	0	10	2.5
7.5	16	4	5	15	3.75
10	20	5	10	20	5

#### Notes:

- 1. Connect the terminals of power source, output respectively and correctly, never make wrong connection.
- 2. The potentiometer can be adjusted, only if necessary, by turning slowly to the required accuracy with a small screwdriver.
- 3. The best accuracy can be achieved when the window is fully filled with current carrying conductor
- 4. The in-phase output can be obtained when the direction of current of current carrying conductor is the same as the direction of arrow marked on the transducer case.